




Tsi381™ (3.3V/Universal) Evaluation Board Release Notes

Important Instructions


1. This evaluation board is configured for 3.3V or Universal PCI plug-in cards only.

The plug-in cards can only be connected with their faceplate oriented the same way as the evaluation board faceplate (see the Correct diagram below).

Correct




Incorrect



2. Do not use a keying adaptor to connect a 5V keyed card on the evaluation board unless the evaluation board has been modified for 5V operation (see the following diagram).

If you need to use the evaluation board with 5V keyed plug-in cards, please contact IDT for assistance.

Incorrect



NOT AN OFFER FOR SALE

The information presented herein is subject to a Non-Disclosure Agreement and is for planning purposes only. Nothing contained in this presentation, whether verbal or written, is intended as, or shall have the effect of, a sale or an offer for sale that creates a contractual power of acceptance.



CORPORATE HEADQUARTERS
6024 Silver Creek Valley Road
San Jose, CA 95138

for SALES:
800-345-7015 or 408-284-8200
fax: 408-284-2775
www.idt.com

for Tech Support:
email: ssdhelp@idt.com
phone: 408-284-8208
document: 80E2000_ZZ001_06