



Tsi381™ Evaluation Board Release Notes (5V/Universal)


Thank you for purchasing the 5V/Universal version of the Tsi381 evaluation board.

Important Instructions


1. This evaluation board is configured for 5V or Universal PCI plug-in cards only.

The plug-in cards can only be connected with their faceplate oriented the same way as the evaluation board faceplate (see the Correct diagram below). Since the evaluation board connectors are keyed for 3.3V cards, a keying adaptor is required when using a 5V keyed card.

Correct




Correct




- Do not use a 3.3V keyed card on the evaluation board. This board has been modified for 5V operation (see the following diagram).

Incorrect



Incorrect



NOT AN OFFER FOR SALE

The information presented herein is subject to a Non-Disclosure Agreement and is for planning purposes only. Nothing contained in this presentation, whether verbal or written, is intended as, or shall have the effect of, a sale or an offer for sale that creates a contractual power of acceptance.



CORPORATE HEADQUARTERS
6024 Silver Creek Valley Road
San Jose, CA 95138

for SALES:
800-345-7015 or 408-284-8200
fax: 408-284-2775
www.idt.com

for Tech Support:
email: ssdhelp@idt.com
phone: 408-284-8208
document: 80E2000_ZZ002_02