

## 1 Introduction

The IDT82V2048 and IDT82V2058 offer several operating modes to suit the many possible design and applications for these LIUs. One of these modes, Hardware Mode will be discussed in this paper. Some functions that are available in Host Control Mode may not be available or may function differently in Hardware Control Mode. Where there are operational differences, these will be noted in the text.

Hardware Control Mode offers the advantage of a lower cost solution and saving of board space. These advantages are realized because a

microprocessor is not required for configuration, thus saving cost and board space. Additional space saving is realized because the signal traces between the microprocessor and LIU are not present.

Hardware Control Mode is achieved by the correct setting of certain multi-function control pins. During power-up or reset, the LIU detects the conditions on the pins and self-configures to operate in the desired mode. The pins involved in Hardware Control Mode configuration are indicated in [Table-1](#).

**Table-1**

Signal Name	Pin No.		Description
	QFP144	BGA160	
MODE2	11	E2	L = Select Hardware Control Mode
MODE1	43	K2	Ground for Hardware Control Mode
CODE	88	H12	L = B8ZS (T1) / HDB3 (E1); H = AMI for all channels
JAS	87	J11	Determines Jitter Attenuator (JA) Configuration, see <a href="#">Table-2</a> .
TS2	86	J12	T1 transmit template select, see <a href="#">Table-3</a> (In 2058, this pin is connected to ground in hardware control mode.)
TS1	85	J13	T1 transmit template select, see <a href="#">Table-3</a> (In 2058, this pin is connected to ground in hardware control mode.)
TS0	84	J14	T1 transmit template select, see <a href="#">Table-3</a> (In 2058, this pin is connected to ground in hardware control mode.)
LP7	28	K1	Configures Channel 7 to loopback according to <a href="#">Table-4</a>
LP6	27	J1	Configures Channel 6 to loopback according to <a href="#">Table-4</a>
LP5	26	J2	Configures Channel 5 to loopback according to <a href="#">Table-4</a>
LP4	25	J3	Configures Channel 4 to loopback according to <a href="#">Table-4</a>
LP3	24	J4	Configures Channel 3 to loopback according to <a href="#">Table-4</a>
LP2	23	H2	Configures Channel 2 to loopback according to <a href="#">Table-4</a>
LP1	22	H3	Configures Channel 1 to loopback according to <a href="#">Table-4</a>
LP0	21	G2	Configures Channel 0 to loopback according to <a href="#">Table-4</a>
OE	114	E14	L sets all TTIPn/TRINGn to high impedance state
CLKE	115	E13	Selects active edge of RCLKn and SCLK; sets active level of RDPn/RDNn
A4	12	F4	Set to GND for Hardware Control mode
MC3	13	F3	Selects Monitor Configuration (see <a href="#">Table-5</a> )
MC2	14	F2	Selects Monitor Configuration (see <a href="#">Table-5</a> )
MC1	15	F1	Selects Monitor Configuration (see <a href="#">Table-5</a> )
MC0	16	G3	Selects Monitor Configuration (see <a href="#">Table-5</a> )

**Table-2**

JAS	Jitter Attenuator (JA) Configuration
L	JA in transmit path
VDDIO/2	JA not used
H	JA in receive path

**Table-3 Built-In Waveform Template Selection (only for 2048)**

TS2	TS1	TS0	Mode	Cable Length	Maximum Cable Loss (dB)
0	0	0	E1	75 $\Omega$ /120 $\Omega$ cable	-
0	0	1	Reserved		
0	1	0	Reserved		
0	1	1	T1	0 – 133ft. ABAM	0.6
1	0	0		133 – 266ft. ABAM	1.2
1	0	1		266 – 399ft. ABAM	1.8
1	1	0		399 – 533ft. ABAM	2.4
1	1	1		533 – 655ft. ABAM	3.0

**Table-4**

LPn	Loopback Configuration
L	Remote Loopback
VDDIO/2	No Loopback
H	Analog Loopback

**Table-5**

MC[3:0]	Monitor Configuration
0000	Normal operation – No monitoring
0001	Monitor Receiver 1
0010	Monitor Receiver 2
0011	Monitor Receiver 3
0100	Monitor Receiver 4
0101	Monitor Receiver 5
0110	Monitor Receiver 6
0111	Monitor Receiver 7
1000	Normal operation – No monitoring
1001	Monitor Transmitter 1
1010	Monitor Transmitter 2
1011	Monitor Transmitter 3
1100	Monitor Transmitter 4
1101	Monitor Transmitter 5
1110	Monitor Transmitter 6
1111	Monitor Transmitter 7

## 2 Operation:

1. Set MODE2 to logic Low to place the IDT82V2048/2058 into Hardware Control Mode.
2. Select either Single Rail or Dual Rail mode for the system side interface (see page 5 of the data sheet for specific instructions).
3. Select the Line Code Rule (AMI/B8ZS/HDB3) by setting the appropriate value on the CODE pin.
4. Set the active edge of RCLK with the CLKE pin.
5. Set the output drivers to high impedance or normal mode with the OE pin.
6. Select the waveform template using TS[2:0] according to [Table-3](#).
7. Set A4 to GND and choose the monitor configuration according to MC[4:0] and [Table-5](#).
8. Choose the Transmit Clock mode according to the pin descriptions on page 5 of the data sheet. This permits the selection between normal mode, TAO, or power down per channel.
9. Optionally select Loopback mode by setting the LPn pins according to [Table-4](#) (Note that Digital Loopback is not available in Hardware Control mode).
10. The JAS pin selects the JA (jitter attenuator) mode according to [Table-2](#).

Note, since Hardware Control Mode does not permit register access, there is no way to access the extended operating modes of the 2048/2058 controlled by the Expanded (indirect) registers.

## IMPORTANT NOTICE AND DISCLAIMER

RENESAS ELECTRONICS CORPORATION AND ITS SUBSIDIARIES (“RENESAS”) PROVIDES TECHNICAL SPECIFICATIONS AND RELIABILITY DATA (INCLUDING DATASHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES “AS IS” AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for developers skilled in the art designing with Renesas products. You are solely responsible for (1) selecting the appropriate products for your application, (2) designing, validating, and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements. These resources are subject to change without notice. Renesas grants you permission to use these resources only for development of an application that uses Renesas products. Other reproduction or use of these resources is strictly prohibited. No license is granted to any other Renesas intellectual property or to any third party intellectual property. Renesas disclaims responsibility for, and you will fully indemnify Renesas and its representatives against, any claims, damages, costs, losses, or liabilities arising out of your use of these resources. Renesas' products are provided only subject to Renesas' Terms and Conditions of Sale or other applicable terms agreed to in writing. No use of any Renesas resources expands or otherwise alters any applicable warranties or warranty disclaimers for these products.

(Rev.1.0 Mar 2020)

### Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan  
[www.renesas.com](http://www.renesas.com)

### Contact Information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:  
[www.renesas.com/contact/](http://www.renesas.com/contact/)

### Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.